

Stainless Steel Accessories

Standard cab sunvisor installation instructions

11/05/2020

1. Remove existing factory Stainless Sunvisor.
2. Drill through rivets on brackets first, using a 1/8" drill bit, followed by a 1/4" drill bit.
3. In the interior, remove the access panel under the center of the upper console, to gain access to the bracket bolting areas.

*NOTE: In some cases the stereo will have to be removed as well.

4. The new stainless steel brackets are marked according to where they go, Their positions are as follows:

SCL- Driver side bracket

SCR- passenger side bracket

SCCI0- Center bracket for 10" Sunvisor

SCC12- Center bracket for 12" Sunvisor

SCC14- Center bracket for 14" Sunvisor

5. Apply a generous amount of silicone caulking to the bracket and roof holes. Then attach the new brackets to the old bracket locations using the supplied 1/4" x 1" bolts (with flat washers under heads) on the lower holes, and 1/4" x 1" bolts (with flat washers) on the top holes, according to their respective positions.
6. Use the large washers on the upper bolts inside the console, and regular washers on the lower bolts above the windshield. Do not tighten the nuts, the brackets must remain moveable at-this point.
7. Set the Sunvisor halves in place starting with the passenger side, use the supplied 10-32 truss head screws, flat washers, and locknuts to attach Sunvisor halves to the brackets. Use the factory bolts to fasten the Sunvisor ends in place (use silicone roof holes.)
8. Once the Sunvisor is sitting in desired position, tighten all hardware and remove the remaining protective coating.



United Pacific

Page 1 of 1

11052020

Reliable. Hardworking. Quality Products.