

Stainless Steel Accessories

Sunvisor extension strip installation instructions

11/19/2020

1. Prepare the surface to be taped as per 3M instructions.
2. Remove 3M tape coating.
3. Using extreme caution, align Sunvisor Extension Strip to the lights in the sunvisor.
4. Working from the center out, applying even pressure to Sunvisor Extension Strip to ensure proper adhesion to factory sunvisor.
5. Drill $3/16$ " holes through endholes.
6. Attach supplied hardware.
7. Remove protective plastic coating.



United Pacific

Page 1 of 1

11192020

Reliable. Hardworking. Quality Products.