



WINDOW VISOR INSTALLATION INSTRUCTIONS

CONTENTS:

- (2) Window Visors
- (2) Alcohol Pads
- (1) Instruction Sheet

NOTE:

If vehicle was recently washed or in the rain, please wait until the window glass channels are completely dry before installing the window visors.

Recommend installation on warm, dry day above 65°F/18°C degrees.

Before installation, please familiarize yourself with a trial fit of the window visor **without** removing the adhesive tape backing.

STEP 1:

Roll down the window and wipe the inside glass channel thoroughly with a clean dry cloth to remove loose dirt. Using the alcohol pad provided, wipe the glass channel where the adhesive tape will attach. Any dirt or dust can weaken the adhesive's strength.

STEP 2:

Peel back the adhesive tape backing about 2" on both ends of the window visor. Insert the lower front end flange into the window channel first, then slide the upper end into position (figure 1). Once window visor is properly placed, slowly and carefully peel the rest of the tape backing strip. Press visor firmly against the inside glass channel surface.

STEP 3:

Raise the window to its closed position and let the visor sit for about 24 hours before operating the window, so the tape has time to adhere to the channel (figure 2).

